

Warnings and Safety Information—Please read carefully!

- Risk of fire and/or electric shock. This product is to be installed by a qualified electrician only. Reflector kit installation requires knowledge of fluorescent lighting luminaire electrical systems. Do not attempt if unqualified.
- This kit is to be installed only in fixtures with construction features consistent with drawings on this sheet.
- Luminaire wiring, ballast or other electrical parts may be damaged when drilling for installation of reflector kit hardware. Check for concealed wiring and components prior to drilling.
- Do not expose wiring to sheet metal edges or other sharp objects to prevent damage.
- If supply wires are located within 3" of the ballast, use feed wire suitable for at least 90°C.
- Install in accordance with all national and local electrical codes. Manufacturer assumes no responsibility for the improper installation or application of this kit.
- Contact the manufacturer for any questions or concerns regarding installation of this kit.

Included Materials

- A: (1) 8' Single Unit Pre-Wired Reflector
A.1: (1) Ballast
A.2: (4) T8 Shunted sockets
A.3: (1) Ballast Disconnect
A.4: (2) Safety Cables
A.5: (1) 6" Ground
E: (8) Self Tapping Tek Screws
F: (4) F32T8 Lamps (Optional)



Installation Instructions

- 1: To avoid the possibility of electrical shock turn off power supply before installation or servicing of this kit.
- 2: Remove lamps, ballast covers, old ballast and sockets from the existing fixture.
- 3: Using provided tek screws and install 14" safety cables (other end attached to cover unit) into existing fixture.
- 4: Wire ballast to incoming power.
- 5: Using supplied tek screws, screw through unitized cover into existing end and center brackets.
- 6: Install lamps and return power to the fixture.

